

# BLACK+ WHITE DANCE FLOOR



EVENT SOURCE  
PANACHE EVENTS

consistently delivering™

**EVENT SOURCE**  
EventSource.com  
877.901.0000

**PANACHE EVENTS**  
PanacheEvents.com  
800.30.PARTY (72789)

#### AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

**Black Dance Floor**  
**SKU 451-4000/4151 INCLUDES**

Full Panels  
Half Panels  
Edging

**White Dance Floor**  
**SKU 453-4000/4961 INCLUDES**

Full Panels  
Half Panels  
Edging



#### NOTE

Never move the trolley without the removable top bar fitted.



## INSTRUCTIONS


### STEP 1



\*Ensure That The Panels Are Flush Along The Top Row

**Row #1:** The first FULL panel is laid at the top left hand corner of the floor with the three “END LUGS” pointing to the left and then the second FULL panel is laid alongside the first with the “END LUGS” pointing to the right. The first two panels just sit next to each other. The third and the rest of the top row FULL panels can now be laid with the “END LUGS” pointing to the right with the bare side of the panel sitting on top of the previous panels “END LUGS”.


### STEP 2



\*Fit the edging by pushing the lugs under the panel rim at an angle and lowering the edge into place. DO NOT FORCE but adjust.

To help keep the top row in place, now fit the edging pieces across the top row starting from the left hand side with a HALF edge and then a FULL edge which will span the joint of the first two FULL panels. Continue fitting the FULL edging pieces with a HALF edge being used at the end of the row to fit flush with the right hand side.

### STEP 3



**Row #2:** The second row starts with a HALF panel again on the left hand side. As with the first row, the “END LUGS” will point to the left. Now complete the row with FULL panels ending with a HALF panel, lugs pointing right..

# BLACK+WHITE DANCE FLOOR



EVENT SOURCE  
PANACHE EVENTS

consistently delivering™

**EVENT SOURCE**  
EventSource.com  
877.901.0000

**PANACHE EVENTS**  
PanacheEvents.com  
800.30.PARTY (72789)

**AFTER HOURS**  
Call above toll free numbers and press  
Option 2. Please leave a message and we  
will respond shortly.

**Black Dance Floor**  
**SKU 451-4000/4151 INCLUDES**

Full Panels  
Half Panels  
Edging

**White Dance Floor**  
**SKU 453-4000/4961 INCLUDES**


Full Panels  
Half Panels  
Edging



**NOTE**  
Never move the trolley without the  
removable top bar fitted.


## INSTRUCTIONS

### STEP 4



**Row #3:** The third row is laid as the first row with FULL panels.

### STEP 5



**Row #4:** The fourth row is laid as the second row starting and ending with a HALF panel.

### STEP 6

**Following Rows:** Continue laying the floor in this fashion until the desired size of floor is achieved.

# BLACK+WHITE DANCE FLOOR



EVENT SOURCE  
PANACHE EVENTS

consistently delivering™

**EVENT SOURCE**  
EventSource.com  
877.901.0000

**PANACHE EVENTS**  
PanacheEvents.com  
800.30.PARTY (72789)

#### AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

**Black Dance Floor**  
**SKU 451-4000/4151 INCLUDES**

Full Panels  
Half Panels  
Edging

**White Dance Floor**  
**SKU 453-4000/4961 INCLUDES**

Full Panels  
Half Panels  
Edging




#### NOTE

Never move the trolley without the removable top bar fitted.




## INSTRUCTIONS

### STEP 7



**Edging:** Now the edging can be completed. The top corner should have laid in operation 2 above. Start now at the top right hand side with a Right hand edge piece followed by a FULL edge. Continue down the right hand side of the floor ending with a left hand corner edge.

### STEP 8



Continue across the bottom row from right to left starting with either a FULL or HALF edge depending on the last row of panels. Continue up the left hand side ending at the top left panel.